

WORLD OF WARCRAFT

WRATH of the LICH KING

PREMIUM BASE ASSEMBLY GUIDE

2

This is a prototype. The final version may differ slightly from the version shown.



F255INS502




FANHOME

DeAgostini
COLLECTIBLES

BILZARD
ENTERTAINMENT

PREMIUM BASE

In this issue, the two remaining plates of the upper platform of the Premium Base will be assembled, completing its structure.



NOTE: The appearance of the parts shown here may be slightly different from the pieces delivered with the issue.


PARTS WITH THIS ISSUE

- 2-1 Connecting plates × 4
- 2-2 Central reinforcing plate
- 2-3 Left front top plate (marked 1)

- 2-4 Right front top plate (marked 4)
- Screws A (13 + 1 extra)

2-4
(MARKED 4)


2-3
(MARKED 1)



2-1 Align the pieces as shown and fit plate 2-4 (marked with a 4) to plate 2-3 (marked with a 1). Bring the edges close together and tilt the plates as shown, so that the small side tabs fit together. At the outer edge, fit the tab on 2-3 into the overhang of 2-4. If necessary, use a little removable tape to hold the pieces together (remove it after Step 2-3).




2-2 Retrieve the plates assembled in the previous issue. To join the two upper halves of the stand, orient the parts as shown in the picture and tilt the two halves until the small side tabs fit together.



2-3 Align the central reinforcing plate 2-2 as shown in the picture and place it in position in the central of the stand. Fix it with five A screws (indicated in red in the image on the right). Place the four connecting plates 2-1 in the indicated positions and fix each one with two A screws, eight in total (indicated in blue in the image on the right).

RESULT



FANHOME

DeAgostini
COLLECTIBLES

BILZZARD
ENTERTAINMENT

©2026 Blizzard Entertainment, Inc.